












Rover, 2009
www.rcdesign.ru

(2, 1)



(3, 1)






H1 (2 pcs.)




H2

Hard monolite foam



Hard monolite foam.
Make this part if use
the wings braces.

H3



F3

(depron 6mm or 2x3mm glued)


F1

(3mm plywood or depron)




L1, L2



(depron 6mm or 2x3mm glued)



F2




(depron 6mm or 2x3mm glued)











(2, 1)



C3



C4





wingtip 6mm depron 2pcs




(1, 1)

Carbon tube 2mm







(1, 1)




(2, 1)



(1, 1)



\perp (2, 1)



+

+

(1, 1)

