





A2
(make 2)




Canopy
(make 11 with 6mm Depron)




Canard wing
(make 2)




Elevators
(make 2)




A1
(make 2)





A4
(make 1)



A6
(make 1)




A5
(make 1)



Nosecone
(make 11 with 6mm Depron)

A



Motor mount
(make 2 and laminate together)

4	3	2	1
---	---	---	---

16

15

14

0 Scale cm

L

Nosecone top view template

K

0 Scale cm

J

0
Scale cm
5
10


I


H


0 Scale cm

G

Top plate assembly drawing







L

K

J

I

H

G



1

2



3

10

5



Aft Fuselage Bottom
(make 1)



Aft Fuselage Slides with Vertical Tails
(make 2)

Laminate 6mm depron

6mm balsa triagle