


Servo Tester User Guide



Servo	Power	Power	Servo Adjuster	Automatic / Manual Setting
	RX Pack / Battery Pack	Loose wire for power as well (4-6 Cell NiMH)		Single Press: Servo will be set to highest position. Double click and Servo would be adjusted to maximum positions (both high and low ends).