
TRANSOM
1/4"


INNER
TRANSOM
1/8"


FRAME #1
1/4"


FRAME #2
1/4"


FRAME #3
1/4"


FRAME #4
1/4"


FRAME #5
1/4"


STRINGER
1/4"
DASHED LINE INDICATES
ANGLE NECESSARY ON
BOTTOM OF STRINGER


SIDE
1 LEFT & 1 RIGHT REQUIRED
1/8"

BOTTOM
1 LEFT & 1 RIGHT REQUIRED
1/8"


DECK
1 LEFT & 1 RIGHT REQUIRED
OR CUT AS ONE PIECE
1/8"
LIP FOR DECK OPENING
2 REQUIRED
1/8"


COCKPIT COVER
1/8"







DOUBLE LINES ALONG EDGE INDICATE
ANGLE REQUIRED FOR CORRECT FIT.
SOLID LINE - ANGLE IS ON THIS SIDE,
DASHED LINE - ANGLE IS ON FAR SIDE